

EUSR-MED



Education and Culture DG

Lifelong Learning Programme



Introduction

How to use the belay device I'D

Belay device I`D

**I`D with
Rope laid in
(device is sealed)**



FD at anchor point

**Anchor point
with round slings**



FD at anchor point

Connection of 2
round slings



I`D at anchor point

I`D fixed at
Anchor point
with round slings



ΓD check

Visual check of
any damages



I`D check

Check if panic-function is working



I'D check

Automatic blocking under load



I`D check

Functioning of the handle



I`D at the harness

**End of rope marked green
attached to the harness**



Mode of working

After the I'D has been fixed at the anchor point, a connection between dynamic rope and harness is established with a connector



**One can give rope only in
a small working range**



**If the handle is given free
the I'D blocks**



If the handle is pushed too hard the I'D blocks also



When the secured person comes back the rope is simply hauled through the I'D .



I'D secured with „Blipknot“

If the safeguard man leaves the I'D the handle has to be put in the park position and the system in addition be secured with a slip stick and a blipknot

